

**Assembly Instruction No. SK14
Tube supports with roller bearing****Montageanleitung Nr. SK14
Rohrträger mit rollender Lagerung****Installs the tube in the support clamp:**

1. Loose the nuts of the cover.
2. Remove the upper cover.
3. Fix the clamp-body, with a wooden wedge, at the required position.
4. Put on the tube. Overhang of tube-ends at least 10mm, max. 50mm
5. Adjust the cover over the tube. Check whether the washers are still in the counter bore of the cover.
6. Please guarantee that the screws are clean and sufficiently greased.
7. Tighten the screws reciprocally with a torque of 75 Nm.
8. Remove the wooden wedge.

Montieren des Rohres im Stützerteil:

1. Lösen der Muttern des Klemmdeckels.
2. Abnehmen des oberen Deckels.
3. Klemmenunterteil mit Hilfe eines Holzkeiles in der erforderlichen Lage fixieren.
4. Rohr einlegen. Überstand bei Rohrenden mindestens 10 mm, maximal 50 mm.
5. Klemmdeckel über das Rohr justieren und überprüfen, ob die Unterlegscheiben noch in der Topfsenkung des oberen Deckels liegen.
6. Bitte sicherstellen, dass die Schrauben noch sauber und ausreichend gefettet sind.
7. Die Schrauben wechselseitig mit einem Drehmoment von 75 Nm festziehen.